

How to Assemble an Overspray Kit (small kit illustrated)



Firstly you need to push the two parts together, you will see an arrow to show which way they should go. They can be quite tight to push together.

Push the top frame through until it is central:



Insert the Fan Jet (or Jets):

Connect the Jet Hose and Straight Connector (or jet hose and T-connector for larger Overspray kit):



Fit the Mount around the brush socket or Vikan adapter and tighten the nut. Connect the Quick-Loq Angle Adapter and connect the hose that feeds through the Angle Adapter to the black Push-Fit Straight Connector.