

Step 2. Set Up - AutoCal

Connect your hose and brush to the pump.

Turn on the controller by pressing the up or down button. Keep the button held until the display lights up.

Press up until the display shows 30.



Press and hold up and enter to go into calibration.



Press down to select AutoCal, then enter to start.



After several moments the calculated Cal value will be displayed and the controller is ready to use. Press enter to exit calibration.



The Cal value can be adjusted manually by following these steps and adjusting the Cal value using up and down, instead of using AutoCal.

To enable or disable the low battery cutoff (when battery is below 10.5V):



Step 3. Use

Press up or down to set a suitable flow of water.



Press enter to display the current battery voltage.



Press enter again to return to the current flow rate.



To turn the controller off, press and hold enter.

Message	Description
	An error has occurred while using AutoCal. This will happen when the motor is not connected or the enter button has been pressed to cancel it.
	Pressure switch activated or motor disconnected.
	A dead end has been detected. If this is not the case, try increasing the Cal value.
	This message will start to flash when the battery is low (<11.0V). If battery is below 10.5V the pump will be disabled to protect the battery. (Unless low battery cutoff is disabled*)